


















CS 26 CAM LIST

NO	ITEM NAME	DRAWING	QTY.	REM	NO	ITEM NAME	DRAWING	QTY.	REM
	Pitch Cam No. 1		2			Taper Cam		2	
	Pitch Cam No. 2		2			Taper Cam		2	
	Pitch Cam No. 3		2			Taper Cam		2	
	Pitch Cam No. 4		2			Arbor Kick Cam		2	
	Pitch Cam No. 5		2			High Speed Cam		1	
	Pitch Cam No. 6		1						
	Pitch Cam No. 7		1			ψ6		1	
					ψ8	1			
					ψ12	1			
	Pitch Cam No. 8		1			Tool Box		1	
					Washer And Bearing For High Speed Cam		1		
					M8*L20 Screw & Washer		2		
	Pitch Cam No. 9		1			M8*L25 Screw & Washer		10	
					13 Wrench		1		
					30 Wrench		2		
					Open Wrench		1 set		
	Pitch Cam No. 10		1			5mm T wrench		1	
					6mm T Wrench		1		
					Hex Wrench		1 set		
					Probe		1		
	Pitch Cam No. 11		1			Grease		1	